


# Smart Mini Dock

Getting started



# Get to know your dock



# Getting started

This dock keeps your Smart Mini reader charged and positioned on your countertop.

## Setting up

Connect the provided USB charging cable to the port found beneath the dock and your power supply.

## Placement

Position your Smart Mini dock on your counter, where customers can easily tap or insert their card/device.

Insert your Smart Mini reader into the dock and your reader will automatically turn on.

# Support

For full user guide and security tips, visit our merchant support hub on [commbank.com.au/merchantsupport](https://commbank.com.au/merchantsupport)

For support please call the CommBank Merchant Helpdesk on **1800 230 177**.

# Warranty

CommBank provides a limited warranty for your Smart Mini dock. For details on warranty and claims, visit [commbank.com.au/smart-mini-warranty](https://commbank.com.au/smart-mini-warranty)

Issued by Commonwealth Bank of Australia  
ABN 48 123 123 124 AFSL 234945

CBA5224 311022